

Mitel 5330 Quick Reference Sheet



What Do These Keys Do?		
	Softkeys (3)	Top left beside display. Used to select/activate a feature that appears in the display. These keys are unlabelled because they will do different things at different times
	UP/DOWN Arrow Keys:	Used to turn volume of caller up & down when on a call and to adjust the ringer volume.
	Speaker:	Used to activate/deactivate loudspeaker.
	Mute:	Enables Mute, for phone's handset, headset or hands-free microphone.
	Settings:	Used for programming Personal keys and accessing various features.
	Cancel:	Used to cancel your last action.
	Redial:	Used to redial the last external number you dialled.
	Hold:	Used to hold calls (not used for transfer).
	Trans/Conf:	Used for enquiry, transfer and conference calls.
	Message:	Used to send and receive messages.
	Personal Keys (24)	These keys may be programmed as LINE, GROUP, STATUS, SPEEDCALL or FEATURE keys, however the bottom Right key is your prime key and cannot be changed - this is your extension.
	Navigation Page Keys:	Used to display additional pages of information, back and next key.

User Information

To specify User Information: Press **Settings** key, select **User Information**, select **Edit Name**, enter your name, select **Save**, Select **Edit Number**, enter your extension number, select **Save**, select **Save**, press **Settings** key.

Answering Calls

To answer a call you may pick up the handset and/or press the flashing key or press **[SPEAKER]**

Internal:	Single ring, prime key flashes, pick up handset, or press flashing key, or press [SPEAKER] . Display shows who is calling you before you answer.
External:	Double ring, prime or line key flashes, pick up handset or press [SPEAKER] and/or press flashing key.
Calls Forwarded to You:	Display shows "from XXXX ", answer as above.

Call Waiting – What Can You Do

While on a call, you hear call waiting tone, you can either hang up and take the waiting call or press **[TRADE]** - this holds your current call and brings the waiting call through

Press **[TRADE]** again to hold the new call and reconnect to your original call

Someone Answer That Phone

Group Pick up:	Lift handset and press PICK UP feature key or *6
To answer any ringing extension	Dial **6 plus the ringing extension number.

Need To Make A Call

Operator Call	Dial 0
Making Internal/Network Calls	Dial the Extension Number you require.
Making External Calls	Dial 9 and the required telephone number <u>or</u>
	Dial System Speedcall code XXXX <u>or</u>
	Press [PHONEBOOK] to look-up internal & system speedial numbers <u>or</u>
	Dial Personal Speedcall code: *1(00-09) <u>or</u>
	Press [REDIAL] key for Last Number Redial.

Hold on I'll Find Out

To hold a call press the **[HOLD]**  key.

To retrieve a held call press the fast flashing line key.

What Is Their Extension Number?

Press "**PHONEBOOK**", use dialpad to display first few letters of the name you want to look up, press "**LOOK UP**", use "**NEXT**" if required and when the correct name appears in the screen press the "**CALL**" key.

I'll Put You Through

To make an enquiry/transfer a call: press **[TRANS/CONF]**  (caller is automatically held), dial required extension number, wait for answer if necessary and either hang up or press **RELEASE** feature key or **HANG-UP** to transfer the call - or press **[CANCEL]**  to return to original call.

Let's Speak To... As Well

Setting up an outgoing conference:

With a call in progress, press  **[TRANS/CONF]**, dial the next person, when they answer, speak privately if required, and when ready, press  **[TRANS/CONF]** again - a conference is established.

Repeat above steps to add additional parties to the conference (maximum of 8).

Setting up an Incoming Conference:

With a call in progress, your second line is flashing, press **[TRANS/CONF]**, select second line to answer call and speak privately, press "**ADD HELD**" softkey, then select first line that was held; a 3 party conference is now established.

To add a further incoming call to your conference, press **HOLD**, then select incoming line key, press **HOLD**, select original line key (flashing quickly) press "**ADD HELD**", press second line flashing, you have a 4 party conference.

Can't Get Through

If the extension you are calling is busy or there is no answer

Press **[MESSAGE]** and hang up - their message lamp will begin to flash immediately or

Press **"CALLBACK"** and hang up. When the extension is free or is next used an automatic callback will take place or

Press **"WAIT"** and do not hang up - the busy extension will hear call waiting tone and can swap to your call, or when they hang up their telephone will ring.

Message Light Is Flashing

Press **[MESSAGE]**, press **"YES"**, the name of the caller is shown, press **"MORE"** for date and time, and press **"CALL"** to be connected.

Going Somewhere

Calls may be forwarded immediately, when you are busy or if you don't answer and may be switched on or off using the **[SETTINGS]** and following the prompts, or by dialling feature access codes shown.

ALWAYS	*81 + destination, forwards all calls to destination
B-INT	*83 + destination, forwards internal calls if you are busy
B-EXT	*84 + destination, forwards external calls if you are busy
B-INT/EXT	*85 + destination, forwards all calls if you are busy
NA-INT	*86 + destination, forwards internal calls on no answer
NA-EXT	*87 + destination, forwards external calls on no answer
NA-INT/EXT	*88 + destination, forwards all calls on no answer

To CANCEL dial above code without dialling the destination.

Secretarial Service

This facility allows the Secretary to control the call forwarding facility from his/her phone.

A DSS/BLF key may be programmed for manager's phone.

To activate Secretarial Service (from SEC phone) dial ***82** plus Manager's extension number or press pre-programmed key.

To cancel Secretarial Service (from SEC phone) dial **#82** plus Manager's extension number or press pre-programmed key.



Programming Personal Keys

Personal Keys may be programmed as SPEEDCALL OR FEATURE keys.

Press **[SETTINGS]**, press the Personal Key to be programmed, press **“View Features”**, use the Navigation Page Keys, to move through features list.

To program an external number or internal extension key, use feature **“SpeedCall”**, press **“Edit Number”**, enter 9 + Tel. Number or Extension Number, press **“Save”**, select **“Edit Label”** and enter Name for key, press **“Save”** and **“Save”** again, press **“Close”** to exit.